




FPDIESEL
FISCHER POPE DIESEL LTD

FOR AP12(E200B/E320B)

ITEM (编号)	DESCRIPTION	名称	QTY (数量)	REMARK (备注)
1-A	VALVE PLATE(E320B)(L/R)	配流盘(E320B)(左/右)	1	
1-B	VALVE PLATE(E200B)(L/R)	配流盘(E200B)(左/右)	1	
2-A	CYLINDER BLOCK(E320B)	泵胆(E320B)	1	
2-B	CYLINDER BLOCK(E200B)	泵胆(E200B)	1	
3-A	COIL SPRING(E320B)	芯弹簧(E320B)	9	
3-B	COIL SPRING(E200B)	芯弹簧(E200B)	9	
4-A	SPACER(E320B)	垫片(E320B)	1	
4-B	SPACER(E200B)	垫片(E200B)	1	
5	BALL GUIDE	球铰	1	
6-A	SET PLATE(E320B)	定位盘(E320B)	1	
6-B	SET PLATE(E200B)	定位盘(E200B)	1	
7	PISTON SHOE	柱塞	9	
8	SHOE PLATE(E200B/E320B)	钢片(E200B/E320B)	1	
9	SWASH PLATE	摇摆盘	1	
10-A	BEARING(E320B)	轴承(E320B)	2	
10-B	BEARING(E200B)	轴承(E200B)	2	
11-A	AXLE SHAFT(E320B)	转轴(E320B)	2	(88X50X40)
11-B	AXLE SHAFT(E200B)	转轴(E200B)	2	(84X50X35)
12-A	DRIVE SHAFT-R(E320B)	驱动轴(右)(E320B)	1	
12-B	DRIVE SHAFT-R(E200B)	驱动轴(右)(E200B)	1	
13-A	DRIVE SHAFT-L(E320B)	驱动轴(左)(E320B)	1	
13-B	DRIVE SHAFT-L(E200B)	驱动轴(左)(E200B)	1	

AP12(E200B,E320B)