


FOR A8V55/59/80/86/107/115/172

ITEM (编号)	DESCRIPTION	名称	QUANTITY (数量)	REMARK (备注)
1	HEAD COVER	泵头盖	1	
2	SERVO PISTON PIN	伺服柱塞销	2	
3	SERVO PISTON	伺服柱塞	2	
4-A	VALVE PLATE (L)	配流盘(L)	1	
4-B	VALVE PLATE (R)	配流盘(R)	1	
5	CYLINDER BLOCK	泵胆	2	
6	DISK SPRING HOLDER	碟簧座	2	
7	DISK SPRING	碟簧	8	
8	SOCKET BOLT	固定螺丝	28	
9	RETAINER PLATE	定位盘	2	
10	CENTER PIN	中心轴	2	
11	RING OF PISTON	柱塞环	14	
12	PISTON	柱塞	14	
13	DRIVE SHAFT(L)	驱动轴(左)	1	
14	DRIVE SHAFT(R)	驱动轴(右)	1	
15	COUPLING	联结	1	
16	LOCK NUT	螺帽	2	



FPDIESEL
FISCHER POPE DIESEL LTD

A8V