



FOR H3V112DP&H5V140/200DP&H5V200DPH

ITEM (编号)	DESCRIPTION	名称	QUANTITY (数量)	REMARK (备注)
1	SPACER OF IDLER GEAR	调整垫片	1	
2-A	IDLER GEAR-L	轮齿轮(右)	1	
2-B	IDLER GEAR-R	轮齿轮(左)	1	
3	SPACER OF BEARING-OUT	调整垫片	2	
4	SPACER OF BEARING-IN	调整垫片	3	
5-A	BEARING-L	轴承-L	1	
5-B	BEARING-R	轴承-R	1	
6	SHIM OF DRIVE SHAFT	调节垫片	2	
7-A	DRIVE SHAFT-L	驱动轴(右)	1	
7-B	DRIVE SHAFT-R	驱动轴(左)	1	
8	SUPPORT	支架	2	
9	SWASH PLATE	摇摆盘	2	
10	SHOE PLATE	钢片	2	
11	PISTON SHOE	柱塞	18	
12	SET PLATE	定位盘	2	
13	BALL GUIDE	球铰	2	
14	COIL SPRING	芯弹簧	18	
15	CYLINDER BLOCK	泵胆	2	
16	VALVE PLATE(L/R)	配流盘(左/右)	2	
17	STOPPER-SMALL	伸缩式塞岩机	2	
18	TILTING PIN	伺服柱塞销	2	
19	SERVO PISTON	伺服活塞	2	
20	STOPPER-BIG	伸缩式塞岩机	2	

H3V112DP&H5V140/200DP&H5V200DPH